

North American TV Channels and Frequency Blocks

By TV Channel in Ascending Order
FREQUENCY MHz



CHANNEL	BLOCK	FROM	TO
2		54	60
3		60	66
4		66	72
5		76	82
6		82	88
7		174	180
8		180	186
9		186	192
10		192	198
11		198	204
12		204	210
13		210	216
14		470	476
15		476	482
16		482	488
17	BL19	488	494
18	486.4	494	500
19	-	500	506
20	511.9	506	512
21	BL20	512	518
22	512.0	518	524
23	-	524	530
24	537.5	530	536
25		536	542
26	BL21	542	548
27	537.6	548	554
28	-	554	560
29	563.1	560	566
30	BL22	566	572
31	563.2	572	578
32	-	578	584
33	588.7	584	590
34	BL23	590	596
35	588.8	596	602
36	-	602	608
37	614.3	608	614
38		614	620
39	BL24	620	626
40	614.4	626	632
41	-	632	638
42	639.9	638	644
43		638	644
44	BL25	644	650
45	640.0	650	656
46	-	656	662
47	665.5	662	668
48		668	674
49	BL26	674	680
50	665.6	680	686
51	-	686	692
52	691.1	692	698
53		698	704
54	BL27	704	710
55	691.2	710	716
56	-	716	722
57	716.7	722	728
58		728	734
59	BL28	734	740
60	716.8	740	746
61	-	746	752
62	742.3	752	758
63		758	764
		764	770

BL470
470.1
-
495.6

Formula for blocks 21-29:
25.6 x block number =
lowest freq. in the block

TV 37 is blocked in BL23

NONE	SPECIAL	944.1	951.9
------	---------	-------	-------

Limited to 8 MHz band